






When the camera is active, ensure no objects are blocking the infrared receiver. Keeping the remote control's IR signal unobstructed guarantees proper operation.




To remove the battery compartment:

1. Press the left-side tab to the right
2. Pull to remove

Uses one CR2032 3V lithium coin battery. Use only specified replacement batteries.



The product's USB port must be inserted into your computer's USB port to connect the camera. The camera itself can be mounted on your computer monitor or installed using a tripod.



Regardless of mounting method, ensure the camera is securely installed in a stable position. Using the camera in an unstable condition may cause it to fall during operation.



www.spedal.tech
support@spedaltech.com


Mac OS System Settings

1. Installation

The camera will install automatically when connected to your computer. No need to manually download or install drivers.


2. Verification

1. Click the Apple menu > "About This Mac" > "System Report"
2. Expand "Hardware - Camera" section. If "Spedal 4K Camera" appears, installation was successful.



3. Audio Input (Microphone) & Output (Speaker) Settings

1. Go to "System Preferences" > Click the "Sound" icon to open audio settings.
2. Under "Input" tab: Select "Spedal 4K Camera Mic" from input devices, then adjust input volume appropriately.
3. Under "Output" tab: Select correct output device, adjust output volume, and ensure "Mute" is unchecked.




Windows System Configuration

1. Installation

The Spedal 4K Camera is compatible with most Windows OS including Windows XP SP2, Windows 7, Windows 8, and Windows 10. Simply connect the camera's USB port to your computer - no additional driver download is required for operation.


2. Verification

- Right-click the Start button and select "Device Manager"
- Expand "Audio inputs and outputs" - successful if "Spedal 4K Camera Mic" appears
- Expand "Cameras" - successful if "Spedal 4K Camera" appears
- Expand "Sound, video and game controllers" - successful if "Spedal 4K Camera Mic" appears




3. Audio Input (Microphone) Configuration

- Right-click the volume icon "🔊" in the taskbar notification area and select "Open Sound settings"
- Under "Input", select "Spedal 4K Camera Mic" from the input device dropdown
- Click "Device properties" under Input, then select "Additional device properties" in Related settings
- In the "Microphone Properties" window:
 - Navigate to "Listen" tab
 - Ensure "Listen to this device" is unchecked
- Under "Levels" tab:
 - Adjust microphone volume appropriately
 - Ensure the sound icon is not muted
- Under "Advanced" tab:
 - Recommended format: "DVD Quality"
 - Ensure "Allow applications to take exclusive control of this device" is checked
 - Ensure "Give exclusive mode applications priority" is checked



4. Audio Output (Speaker) Configuration

- Right-click the volume icon "🔊" on the taskbar and select "Open Sound settings"
- Under "Output", select "High Definition Audio Device" from the output device dropdown
- Click "Device properties" under Output, then select "Additional device properties" in Related settings
- In the "Speaker Properties" window:
 - Navigate to "Levels" tab
 - Adjust microphone volume appropriately
 - Ensure the sound icon is not muted
- Under "Enhancements" tab:
 - Ensure "Disable all Enhancements" is unchecked
- Under "Advanced" tab:
 - Do not select the same quality as the microphone
 - Recommended format: "Studio Sound Quality" or higher



5. Camera Video Recording

- Click the Start menu and open the "Camera" application
- In video mode, click the "📹" video icon to start recording
- In photo mode, click the "📷" camera icon to capture images

